

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



PLUG

Cat. No. 100M

Male Inline

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470152 0315

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

MARINCO®

marinco.com
800-307-6702

470152 0315

MARINCO®

marinco.com
800-307-6702

470152 0315

MARINCO®

marinco.com
800-307-6702

470152 0315

MARINCO®

marinco.com
800-307-6702

470152 0315

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

bates®



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

MARINCO®

marinco.com
800-307-6702

470152 0315

MARINCO®

marinco.com
800-307-6702

470152 0315

MARINCO®

marinco.com
800-307-6702

470152 0315

MARINCO®

marinco.com
800-307-6702

470152 0315