GROUP 5[®]

G100 Family 100A 125V Stage Pin Wiring Instructions

- Use #2 or #4 Type SC single conductor cable (grounding wire can be #6 minimum), or use 4/3 or 6/3 Type W multiconductor cable.
- When using Type SC cable, use gaffers tape to secure the three wires together in a bundle where they pass through the housing at the strain relief.
- For applications needing 4/3 S-jacketed cable, use G100M-DB or G100F-DB which have a wider jacket opening.
- Strip the conductors 3/4".
- Two versions of wire termination are available.
- 1. Slide wire shoe (ferrule) over each wire and insert into appropriate terminal pocket.
 - -Green wire into terminal marked "G"
 - -White wire into terminal marked "N"
 - -Black wire into terminal marked "H"
 - -Tighten ¼"-28 double set screws to 30 in-lbs torque with 5/32" hex (allen) head wrench.
- Crimp a #4 ring terminal onto white and black wires.
 - -Crimp a #6 ring terminal onto green wire.
 - -Green wire to terminal marked "G"
 - -White wire to terminal marked "N"
 - -Black wire to terminal marked "H"
 - -Place washer over ring terminal.
 - -Attach to the appropriate terminal with the 1/4"-20 terminal screw at 30 in-lbs torque.
- Place cover over housing and tighten the three ¼"-20 flat head screws to 14 in-lbs. torque.
- · Device is now ready for use.

GROUP 5[®]

G100 Family 100A 125V Stage Pin Wiring Instructions

- Use #2 or #4 Type SC single conductor cable (grounding wire can be #6 minimum), or use 4/3 or 6/3 Type W multiconductor cable.
- When using Type SC cable, use gaffers tape to secure the three wires together in a bundle where they pass through the housing at the strain relief.
- For applications needing 4/3 S-jacketed cable, use G100M-DB or G100F-DB which have a wider jacket opening.
- Strip the conductors 3/4".
- Two versions of wire termination are available.
- 1. Slide wire shoe (ferrule) over each wire and insert into appropriate terminal pocket.
 - -Green wire into terminal marked "G"
 - -White wire into terminal marked "N"
 - -Black wire into terminal marked "H"
 - -Tighten ¼"-28 double set screws to 30 in-lbs torque with 5/32" hex (allen) head wrench.
- Crimp a #4 ring terminal onto white and black wires.
 - -Crimp a #6 ring terminal onto green wire.
 - -Green wire to terminal marked "G"
 - -White wire to terminal marked "N"
 - -Black wire to terminal marked "H"
 - -Place washer over ring terminal.
 - -Attach to the appropriate terminal with the ½"-20 terminal screw at 30 in-lbs torque.
- Place cover over housing and tighten the three ¼"-20 flat head screws to 14 in-lbs. torque.
- · Device is now ready for use.

G100 Family 100A 125V Stage Pin Wiring Instructions

GROUP 5®

- Use #2 or #4 Type SC single conductor cable (grounding wire can be #6 minimum), or use 4/3 or 6/3 Type W multiconductor cable.
- When using Type SC cable, use gaffers tape to secure the three wires together in a bundle where they pass through the housing at the strain relief.
- For applications needing 4/3 S-jacketed cable, use G100M-DB or G100F-DB which have a wider jacket opening.
- Strip the conductors 3/4".
- Two versions of wire termination are available.
- 1. Slide wire shoe (ferrule) over each wire and insert into appropriate terminal pocket.
 - -Green wire into terminal marked "G"
 - -White wire into terminal marked "N"
 - -Black wire into terminal marked "H"
 - -Tighten ¼"-28 double set screws to 30 in-lbs torque with 5/32" hex (allen) head wrench.
- 2. Crimp a #4 ring terminal onto white and black wires.
 - -Crimp a #6 ring terminal onto green wire.
 - -Green wire to terminal marked "G"
 - -White wire to terminal marked "N"
 - -Black wire to terminal marked "H"
 - -Place washer over ring terminal.
 - -Attach to the appropriate terminal with the 1/4"-20 terminal screw at 30 in-lbs torque.
- Place cover over housing and tighten the three ¼"-20 flat head screws to 14 in-lbs. torque.
- Device is now ready for use.

PN 202659 0315