



PLUG









PLUG

Cat. No. 106M

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- · Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws-use 5/32" allen head wrench and tighten to 30 in/lbs torque.

(VL)

LISTED

5372

Cat. No. 106M

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".

bates

· Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

Cat. No. 106M

PLUG

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- · Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

Cat. No. 106M

PLUG

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- · Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470153 0315



PLUG

Cat. No. 106M

Male Inline / 250V

Cat. No. 106M

470153 0315

PLUG

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- · Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torgue.

470153 0315



PLUG

Cat. No. 106M

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- · Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws—use 5/32" allen head wrench and tighten to 30 in/lbs torque.





PLUG

470153 0315

Cat. No. 106M

Male Inline / 250V

INSTRUCTIONS

- Use with #2 Type SC single conductor cable.
- Strip conductor 1-1/4".
- · Slide wire shoe (ferrule) over each wire bundle and insert into terminal pocket and secure with 2 each 5/16-24 set screws-use 5/32" allen head wrench and tighten to 30 in/lbs torque.

470153 0315

470153 0315

5372

bates[®]

 Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.

LISTED

5372

LISTED

- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).



 Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.

LISTED

- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).



LISTED

5372



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

MARINCO

marinco.com 800-307-6702 470153 0315



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

MARINCO

marinco.com 800-307-6702 470153 0315



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

MARINCO

marinco.com 800-307-6702 470153 0315

LISTED

- bates
- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.

ŰL

LISTED

- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).

MARINCO

marinco.com 800-307-6702 470153 0315

bates



- Bates strain relief system offers maximum wire opening diameter of 0.915" without inserts. Inserts (2) can be used in varying configurations down to 0.260" diameter.
- Select the combination best suited to your application, locate cover and tighten the forward screws (2 ea. 1" x 1/4-20).
- Complete assembly with rear screws (2 ea. 1-1/4" x 1/4-20).



marinco.com 800-307-6702 470153 0315



marinco.com 800-307-6702 470153 0315

MARINCO marinco.com

470153 0315



marinco.com 800-307-6702 470153 0315